
REQUIRED/RECOMMENDED TOOL LIST FOR ALTECH-ECO CNG CONVERSIONS

2011-2013 FORD TRANSIT

1. Methane Detector – One can be recommended by Altech-Eco.
2. Torque Wrench, 3/8" Drive and open head wrench.
3. Hole Saw: 3 1/2", 29mm, 2 1/2".
4. Wrench: 11/16", 7/8", 3/4", 19mm, 22m, 13/16".
5. Socket: 3/4, 19mm, 10mm, 13mm, 8mm, 5/8", 3/8", 24mm, 15mm, 1 1/16".
6. Screw Drivers: Flat head and Philips Head.
7. Drill Bit: 3/4", 9/16", 3/8", 1/8" long bit for pilot holes.
8. 1/4" and 3/8" drive half size extension (x) 2.
9. Allen Wrench Socket: 1/8", 3/16".
10. Zip Tie Clippers.
11. Fuel Line Disconnecter.
12. Hose Cutters.
13. Hose Clamps (to restrict fluid flow).
14. Hose Clamp Tool/Pliers.
15. Clip Removal Tool.
16. Half Round and Triangle file.
17. Uni-bit up to 1 3/8".
18. Silicone Gun + Silicone.
19. Self Tapping screw socket heads: 5/16", 3/8".
20. Star Socket (T27 Sears).
21. Terminal Removal Tool (aka Depinner).
22. Soldering Kit w/ Heat Gun and Solder.
23. Mini Squeegee for decals.
24. Filter Socket (Altech-Eco).
25. Knife/Blade.
26. Wire Strippers.
27. Touch up, paint/primer.
28. Tape Measure.
29. Black Electrical Tape.
30. Ratchet: 3/8", 1/4" drive.